

Installing Poppet Valve



1. Insert o-ring.



2. Insert poppet valve point down.



3. Screw in screen fitting hand tight.



4. Done.